



COPPER BASIN INSTALLATION INSTRUCTIONS

Vessel Basins

General Installation Notes:

- Observe and conform to all local building and plumbing codes.
 - All Native Trails basins should be installed by professional installers.
 - As our basins are hand crafted and dimensions are approximate, we recommend using the actual basin for the cut-out.
 - Different countertop materials will require different methods of cutting and may have other specific needs such as exposed areas of wood that may need waterproofing for undermounting.
 - Make sure a watertight seal exists on all drain connections.
 - DO NOT place basin directly on floor. After unpacking, place basin on protective material such as foam molds from the packaging.
 - **Remember to always use non-abrasive cleaners on Native Trails basins. Mild soap and water is recommended. Refer to Care and Maintenance Instructions for further information.**
 - If unsure which instructions pertain to your product call our Customer Service Department at 800-786-0862.
1. Measure drain opening and mark countertop for drain opening.
 2. Cut countertop for drain opening.
 3. Place basin on top of countertop and make sure that the drain opening sits down inside of countertop.
 4. Use a level to make sure that the basin is sitting level in all directions, front to back and side to side.
 5. Install the drain according to the drain's installation instructions.
 6. The hold down nut of the drain pipe will secure the basin to the countertop.
 7. You may use a bead of clear silicone to seal in-between the outside edge of vessel where it is mounted to the countertop.

When cleaning up after installations, DO NOT USE ABRASIVE CLEANERS, as they may scratch and change the basin surface and finish. Use warm water, a soft cloth and a non-abrasive soap (such as dish soap) to clean the surface. Refer to Care and Maintenance Instructions for further information.

** For installation of the Palisades basin, *before* cutting the countertop, turn basin over and measure from the *bottom inner edge of the apron* to the front edge of the basin (approx. 2.5"). This will provide the measurement for determining where to cut/place the basin so the apron front extends properly over the edge of the countertop.