



## WALL AND CORNER MOUNT INSTALLATION INSTRUCTIONS

### General Installation Notes:

- Observe and conform to all local building and plumbing codes.
- Wall and Corner Mount should be installed by professional installers.
- Make sure a watertight seal exists on all drain connections.
- **Remember to always use non-abrasive cleaners on Native Trails basins. Mild soap and water is recommended. Refer to Care and Maintenance for further information.**

### VILLA WALL MOUNT

- Check the ADA specified height or determine desired height.
- Mount the wall bracket. The wall bracket holes may or may not line up with beams in the wall. Toggles will have to be used if no beams are available.
- After the wall mount bracket is mounted, apply silicon to the top of the bracket. Place the Villa Wall Mount unit on the bracket, making sure it is flush to the wall.
- Allow the silicon to dry.
- Install drain according to the drain's installation instructions.

### VILLA CORNER MOUNT

- Check the ADA specified height or determine desired height.
- Mount the corner bracket. The corner bracket has holes in it that should line up with beams in the wall at the corner and 16" from the corner both ways. Make sure the 2 tabs are up.
- After the corner bracket is mounted, apply silicon to the top of the bracket. Place the Villa Corner Mount unit on the bracket, making sure it is flush to the wall.
- Allow the silicon to dry.
- Install drain according to the drain's installation instructions.

When cleaning up after installations, **DO NOT USE ABRASIVE CLEANERS**, as they may scratch and change the basin surface and finish. Use warm water, a soft cloth and a non-abrasive soap (such as dish soap) to clean the surface. Refer to Care and Maintenance Instructions for further information.